

**EN: (Crude) Installation instructions:**

(without guaranty)

1. Drain the coolant from the original cooling circuit.
2. Replace the original pump with the new one.
3. Connect the large plug of the adapter cable to the new pump and the small plug to the original connection of the vehicle.
4. Refill the coolant and **vent** the cooling system if necessary. (Vehicle specific)
5. If the pump does not work, you can cut the gray / red cable of the adapter to run the pump at full speed as it gets power. Be sure to **insulate** the **snipped cable** ends.

- - - - -

**DE: (Grobe) Einbauanleitung:**

(ohne Gewähr)

1. Lassen Sie das Kühlmittel des originalen Kühlkreislaufes ab.
2. Tauschen Sie die originale Pumpe gegen die neue Pumpe aus.
3. Verbinden Sie den großen Stecker des Adapterkabels mit der neuen Pumpe und den kleinen Stecker mit dem originalen Stecker des Fahrzeugs.
4. Füllen Sie das Kühlmittel wieder auf und **entlüften** Sie gegebenenfalls das Kühlsystem. (Fahrzeugspezifisch)
5. Falls die Pumpe nicht funktioniert können Sie das grau/rote Kabel des Adapters durchtrennen um die Pumpe mit voller Geschwindigkeit laufen zu lassen. Achten Sie darauf die durchtrennten **Kabelenden** zu **isolieren**.